

# REPAIR PARTS MANUAL MODEL NO. AB12596E Lawn Tractor



# **HOW TO USE THIS MANUAL**

This manual is designed to provide the customer with a means to identify the parts on his/her tractor when ordering repair parts. The illustrations may or may not represent the actual assemblies; therefore, it is not recommended to use this manual as a guide to assemble or disassemble the tractor. Some hardware and parts are drawn larger in order to more readily identify them.

Each tractor has its own model number.

The model number for your tractor can be found on the fender under the seat.

When ordering parts, always give the following information:

- Product "Lawn Tractor"
- Model Number "AB12596E"
- Part Number
- Part Description

# TABLE OF CONTENTS

SCHEMATIC	3
ELECTRICAL	4-5
CHASSIS AND ENCLOSURES	6-7
DRIVE	8-9
SEAT	10
DECALS	11
STEERING WHEEL	12-13
ENGINE	14-15
MOWER LIFT	16-17
MOWER DECK	18-19
WARRANTY	22

#### TRACTOR - - MODEL NUMBER AB12596E

#### **SCHEMATIC**

RUN


**START** 

NONE

NONE

B+A1


B + S + A1



**NOTE:** IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.

#### TRACTOR - - MODEL NUMBER AB12596E

#### **ELECTRICAL**



#### TRACTOR - - MODEL NUMBER AB12596E


#### **ELECTRICAL**

KEY NO.	PART NO.	DESCRIPTION
1	144925	Battery 12 Volt 25 AMP
2	74760412	Bolt Hex Hd 1/4-20unc X 3/4
8	156417	Case Battery
16	153664	Switch Interlock Push-In
21	166181	Harness Asm Light W/4152j
22	4152J	Bulb Light #1156
24	4799J	Cable Battery
25	146147	Cable Battery 6 Ga 44" red
26	175158	Fuse 20 AMP
27	73510400	Nut Keps Hex 1/4-20 Unc
28	4207J	Cable Ground 6 Ga 12" black
29	121305X	Switch Plunger Nc Gray
30	175566	Switch Ign
33	140401	Key Ign
40	170217	Harness Ignition
41	71110408	Bolt Blk Fin Hex 1/4 - 20 x 1/2
42	131563	Cover Terminal Red
43	175141	Solenoid
48	140844	Adapter Ammeter
52	141940	Protection Wire Loop

**NOTE:** All component dimensions give in U.S. inches 1 inch = 25.4 mm.

# TRACTOR - - MODEL NUMBER AB12596E

#### **CHASSIS AND ENCLOSURES**



# TRACTOR - - MODEL NUMBER AB12596E


#### **CHASSIS AND ENCLOSURES**

KEY NO.	PART NO.	DESCRIPTION
1	169831	Chassis
2	176554	Drawbar
3	17060612	Screw, 3/8-16 x 3/4 SMGML Tap/R
5	155272	Bumper Hood/Dash
6	155924X011	Saddle Flat
8	155138	Clip Retainer Slide-On
9	168347X011	Dash P/L
10	72140608	Bolt, Rdhd Sqnk 3/8-16 x 1
11	155927	Panel Asm.Dash LH
12	145660	Clip Tinnerman Grille P/L
13	172107X010	Dash, Panel RH
15	74180512	Screw Mach.Trhd 5/16-18 UNC x 3/4
16	73510500	Nut Keps 5/16-18 UNC
17	159639X505	Hood Pnt Stl PL
18	126938X	Bumper Hood
24 25	74780616	Bolt, Hex , Fin. 3/8-16UNC x 1 Gr. 5
25 26	19131312	Washer 13/32 x 13/16 x12 Gauge Nut Lock Hex w/lns. 3/8-16 Unc
28 28	73800600 150407	Grille
29	150209X599	Lens Grille
30	169465X505	Fender Pnt
31	136619	Bracket Fender
33	145244X505	Footrest Pnt., LH
34	145243X505	Footrest Pnt., RH
35	72110606	Bolt Rdhd Sht. Sqnk 3/8-16 X 3/4
37	17490508	Screw Thdrol 5/16-18 x 1/2 Tyt
38	169834	Bracket Asm Pivot Mower Rear
51	73800400	Nut Lock Hex W/Ins 1/4-20
52	19091416	Washer 9/32 x 7/8 x 16 Ga.
53	144697	Bracket, Grille LH
54	161464	Screw Hex WSHD 8-18 x 7/8
55	144696	Bracket Grille RH
57	74780412	Bolt Fin Hex 1/4-20 x 3/4
58	150127	Duct Air Engine
145	156524	Rod Pivot Chassis/Hood
206	170165	Bolt Shoulder 5/16-18
208	17670608	Screw Thdrol 3/8-16 x 1/2
209	17000612	Screw Hex Wsh Thdr 3/8-16 x 3/4
212	156494	Insert Lens Reflect
	5479J	Plug Btn Blk .359 Dia Ch/Inf

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm

#### TRACTOR - - MODEL NUMBER AB12596E

#### **DRIVE**




#### TRACTOR - - MODEL NUMBER AB12596E

#### **DRIVE**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1		Transaxle (See Breakdown) Peerless,	48	154407	Bellcrank Asm Clutch
		Model 205-544C	49	123205X	Retainer, Belt
		Order parts from transaxle	50	74760624	Bolt, Hex 3/8-16 x 1-1/2
_	4.40000	manufacturer	51	73680600	Nut, Crownlock 3/8-16
2	146682	Spring, Brake Return	52	73680500	Nut, Crownlock 5/16-18
3	123666X	Pulley, Transaxle	53	105710X	Link, Clutch
4	12000028	Ring, Retainer	55	105709X	Spring, Return, Clutch
5	121520X	Strap, Torque	56	74760620	Bolt, Fin, Hex 3/8-16unc x 1-1/2
6	17060512	Screw, 5/16-18 x 3/4 SMGML	57	130801	V-Belt, Drive
7	162240	Bracket, T/A, Saddle Shift	59	169691	Keeper Belt Center Span
8	131679	Rod, Shifter	61	17060612	Screw, 3/8-16 x 3/4 SMGML
10	76020416	Pin, Cotter 1/8 x 1	62	8883R	Cover, Foot Pedal
11 12	105701X	Washer, Shift Plate	63	140186	Pulley, Engine
13	19151216	Washer 15/32 x 3/4 x 16 Bolt 1/4-28 UNF Gr. 8 w/Patch	64 65	71170764	Bolt, Hex 7/16-20 x 4 Gr. 5
13 14	74550412 10040400	Washer Lock	66	10040700 154778	Washer, Lock Hvy Hlcl Spr 7/16
18	74780616	Bolt, Fin Hex 3/8-16 Unc x 1 Gr. 5	70	134683	Keeper, Belt Engine F-Proof Guide Belt Mower Drive RH
19	73800600	Locknut 3/8-16	70 74	137057	
21	106933X	Knob	74 75	137037 121749X	Spacer, Split Washer 25/32 x 1-1/4 x 16 Ga.
22	130804	Rod, Brake	76	12000001	E-Ring
24	<b>73350600</b>	Nut, Hex Jam 3/8-16	77	123583X	Key Square
25	106888X	Spring, Rod, Brake	78	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
26	19131316	Washer 13/32 x 13/16 x 16 Gauge	79	2228M	Key Woodruff #9 3/16 x 3/4
27	76020412	Pin, Cotter 1/8 x 3/4	96	4497H	Retainer Spring 1" Ziinc/Cad
28	145204	Rod, Brake, Park	112	19091210	Washer 9/32 x 3/4 x 10 Ga.
29	124236X	Cap, Plunger	113	127285X	Strap Torque L.H. Lt
30	174973	Bracket, Transaxle	116	72140608	Bolt, RdHd Sq Neck 3/8-16 x 1.25
32	74760512	Bolt Hex Hd 5/16-18 UNC x 3/4	120	73900600	Nut Lock Flange 3/8-16
34	155071	Shaft, Foot Pedal	145	74490540	Bolt, Hex Flghd 5/16-18 Gr. 5
35	120183X	Bearing Nylon	150	165850	Bushing, Bellcrank Grd Dr.
36	19211616	Washer 21/32 x 1 x 16 Gauge	151	19133210	Washer 13/32 x 2 x 10 Ga.
37	1572H	Pin,Roll 3/16 x 1	170	173898	Keeper, Belt Tap Pmst/Dan
38	131494	Idler, Flat	202	72110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr. 5
39	74760644	Bolt Fin Hex 3/8-16 x 2-3/4	212	145212	Nut Hex Flange Lock
40	4470J	Spacer	-	-	3. 3.
41	165838	Keeper, Belt	NOTE		onent dimensions give in U.S. inches.
42	19131312	Washer 13/32 x 13/16 x 12 Gauge		1 inch = 2	5.4 mm.
47	127783	Pulley, Idler			

### TRACTOR - - MODEL NUMBER AB12596E


#### **SEAT**



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	127427	Seat	14	72050412	Nut, Crownlock 1/4-20 x 1-3/8
2	140551	Bracket, Pivot, Seat	15	134300	Spacer, Split
3	71110616	Fin Hex 3/8-16unc x 1	16	121250X	Spring
4	19131610	Washer 13/32 x 1 x 10 Ga.	17	123976X	Nut, Lock, Flange 1/4 Gr. 5
5	145006	Clip, Push-in	21	171852	Bolt, Shoulder 5/16-18 UNC-2A
6	73800600	Nut	22	73800500	Nut
7	124181X	Spring, Seat	23	71110814	Bolt Hex
8	17000616	Screw, 3/8-16 x 1.5 SMGML Tap/R	24	19171912	Washer 17/32 x 1-3/16 x 12 Ga.
9	19131614	Washer 13/32 x 1 x 14 Ga.	25	127018X	Bolt Shoulder 5/16-18 x .62
10	174894	Pan, Seat	26	10040800	Washer Lock Hvy Hclc Spr 1/2
12 13	121246X 121248X	Bracket, Mounting, Switch, Seat Bushing, Nylon	NOTE	E: All compo	nent dimensions given in U.S. inches


#### TRACTOR - - MODEL NUMBER AB12596E

#### **DECALS**



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	145498	Decal, Instruction, Operation	13	175829	Decal, Wheel Steering
2	163520	Decal, Fender	14	145005	Decal, Btry Dngr/Psn P/L Sym
3	167918	Decal, Hood RH	15	136832	Decal, V-Belt
4	167919	Decal, Hood LH	16	134999	Decal, Deck Enviro
5	159713	Decal, Panel Side	19	140837	Decal, Parking Brake
6	159736	Decal, Chassis Hot Muffler		133671	Pad, Footrest
7	159737	Decal, Brake/Clutch Symbol LT		138311	Decal, Handle, Lift, Height Adjust
8	145437	Decal, Europe Stand ČE			(Lift Handle)
9	170841	Decal, HP Engine		162598	Decal, Drawbar Load Limit
11	145494	Decal, Mower Cutfinger Symbol		177645	Manual, (Euro) Operator's
12	126187X	Decal 100 DBA		177647	Manual, Repair Parts

#### **TIRES AND WHEELS**




KEY NO.	PART NO.	DESCRIPTION
1	59192	Cap, Valve
2	65139	Stem, Valve
3	106222X	Tire Front
4	59904	Tube, Front (not furnished)
5	106732X427	Rim, Asm. Front
6	278H	Grease Fitting (rear tire only)
7	9040H	Bearing, Flange (front tire only)
8	106108X427	Rim, Asm. Rear
9	124635X	Tire, Rear
10	7152J	Tube, Rear (not furnished)
11	<b>104757X428</b>	Cap, Axle
	144334	Sealant, Tire (10 oz. Tube)

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm

### TRACTOR - - MODEL NUMBER AB12596E

#### STEERING WHEEL



#### TRACTOR - - MODEL NUMBER AB12596E


#### STEERING WHEEL

KEY NO.	PART NO.	DESCRIPTION
NO. 1 2 3 4 5 6 7 8 9 10 11 13 15 17 18 19 22 32 526 27 28 29 30 32 36 37 38 39 40 41 42 43 44 64 47 51	NO. 121472X 154427 169840 169839 6266H 121748X 19272016 12000029 3366R 169832 10040600 136518 145212 156546 57079 160395 165857 165851 154406 126847X 136874 19131416 17060612 76020412 130465 155099 152927 126805X 19133812 7810H 100711L 145054X428 121749X 153720 121232X 6855M 73800500	Wheel Steering Axle Asm Front Spindle Asm LH Spindle Asm RH Bearing, Race, Thrust Hardened Washer 25/32 X 1-5/8 X 16 Ga Washer 27/32 X 1-1/4 X 16 Ga Ring Klip Bearing Link Drag Washer Lock Hvy Hlcl Spr 3/8 Spacer Brg. Axle Front Nut Hexflange Lock Steering, Assembly Shaft Washer Thrust 515x 750x 033 Support Shaft Screw Hex WSHHD Torx Shaft Asm Pittman Bracket Steering Bushing Link Drag Blk Lr Gear Sector Washer 13/32 x 7/8 x 16 Ga. Screw 3/8-16x3/4 SMGML Tap/R Pin Cotter 1/8 x 3/4 CAD Rod Connecting Bushing Steering Screw TT #10-32 X 5 x 3/8 Flange Cap Wheel Steering Washer 13/32 x 2-3/8 x 12 Ga Nut Lock Center 3/8-24 Unf Adapter Wheel Strg Boot Steering Washer 25/32 X 1 1/4 X 16 Ga Extension Steering Cap Spindle Fitting Grease Nut Lock Hex W/Ins. 5/16-18 Unc P
51 54 62	73800500 74780520 167902	Nut Lock Hex W/Ins. 5/16-18 Unc P Bolt Fin Hex 5/16-18 Unc 6 x 1-1/4 Kit Steering Asm. Service
63 65 66 67 68 79 80 82 85	74780616 160367 154404 72140618 169827 19132012 74950612 169835 133835	Bolt Fin Hex 3/8-16unc x 1 Gr. 5 Spacer Brace Axle Bearing Arm Pittman Bolt RDHD SQ 3/8-16UNC x 2-1/4 Brace Axle Washer 13/32 x 1-1/4 x 12 Bolt, Hex Nylon 3/8-16 x 3/4 Bracket Susp. Chassis Front Fastener Christmas Tree

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm

#### TRACTOR - - MODEL NUMBER AB12596E

#### **ENGINE**



#### TRACTOR - - MODEL NUMBER AB12596E


#### **ENGINE**

KEY NO.	PART NO.	DESCRIPTION
1	170865	Control Th/ch
2	17720410	Screw Hex Thd Cut 1/4-20x5/8 T
3		Engine, B&S Model 289707 Order parts from engine manufacturer
4	137348	Muffler Exhaust
13	165291	Gasket Muffler
14	148356	Tube Drain Oil Easy
16	11050600	Washer Lock Ext Tooth 3/8
23	169837	Shield BRN/DBR Guard
29	137180	Kit Spark Arrestor (Flat Scrn)
31	109202X	Tank Fuel Front
32	140527	Cap Asm Fuel
33	123487X	Clamp Hose Blk Line Fuel
37 38	137040 <b>148315</b>	
30 40	124028X	Plug Drain Oil Easy Bushing Snap Nyl Blk Fuel Line
44	17670412	Screw Hexwsh Thdrol 1/4-20x3/4
45	17070412	Screw Hex Wsh Thdrol 3/8-16
46	19091416	Washer 9/32 X 7/8 X 16 Ga
62	10040500	Washer 5/16
66	127951	Stop Throttle
72	71070512	Screw Hex Hd Cap 5/16-18 x 3/4
78	17060620	Screw 3/8-16x1-1/4 SMGML Tap/R
81	73510400	Nut Keps Hex 1/4-20 UNC

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

#### TRACTOR - - MODEL NUMBER AB12596E

#### **MOWER LIFT**



#### TRACTOR - - MODEL NUMBER AB12596E


#### **MOWER LIFT**

KEY NO.	PART NO.	DESCRIPTION
1	159460	Wire Asm. Inner/Sprg w/Plunger
2	159471	Shaft, Asm., Lift R/H
3	105767X	Pin, Groove
4	12000002	Ring, E #5133-62
5	19211621	Washer 21/32 x 1 x 21 Ga.
6	120183X	Bearing, Nylon
7	109413X	Grip Handle Bicycle Matte Blk
8	122365X	Button, Plunger
11	139865	Link, Lift, Lh
12	139866	Link, Lift, Rh
13	4939M	Spring, Retainer
15	173288	Link, Front
16	73350800	Nut, Jam, Hex 1/2-13 Unc
17	130171	Trunnion
18	73680800	Nut, Crownlock 1/2-13 Unc
19	139868	Arm, Suspension, Rear
20	163552	Spring, Retainer Zinc
31	169865	Bearing, Pvt Lft
32	73540600	Nut Crownlock 3/8-24

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm

#### TRACTOR - - MODEL NUMBER AB12596E

#### **MOWER DECK**



#### TRACTOR - - MODEL NUMBER AB12596E

#### **MOWER DECK**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	170280	Deck Asm Weldment	67	106932X	Knob Rd 3/8-16 Plstc Thds Blk
2	72140506	Bolt	68	144200	V-Belt, Mower
3	138017	Asm., Bar, Anti-Sway	69	76020312	Pin, Cotter 3/32 x 3/4
4	169970	Bracket Sway Bar Deck 38/42"	86	7631J	Runner, LH
5	4939M	Spring, Retainer	87	128772	Runner, RH
6	130832	Arm, Šuspension, Rear	88	19111216	Washer 11/32 x 3/4 x 16 Ga.
8	850857	Bolt 3/8-24 x 1.25 Gr. 8	89	19131612	Washer 13/32 x 1 x 12 Ga.
9	10030600	Washer, Lock	107	133502	Retainer
10	140296	Washer, Hardened	108	133503	Stiffener, Idler Arm
11	138497	Blade, Mower, Hi Lift	109	74760640	Bolt, hex Head 3/8-16 x 2-1/2
13	137645	Asm., Shaft, Mandrel, Vented	110	142587	Upstop Deck Front 38"
14	128774	Housing, Mandrel, Vented	113	17060512	Screw, 5/16-18 x 3/4
15	110485X	Bearing, Ball, Mandrel	122	131289	Rod, Brake, LH
16	174493	Stripper, Mower	123	169971	Rod, Brake, RH
19	132827	Bolt, Shoulder	146	165891	Bolt Carriage Idler
21	73680500	Nut, Crownlock 5/16 - 18 UNC	148	169022	Spring Return Idler
23	137607	Bracket, Deflector	149	165898	Retainer Spring Yelow Zinc
24	105304X	Cap, Sleeve	150	19091216	Washer 9/32 x 3/4 x 16 Ga.
25	123713X	Spring, Torsion, Deflector	151	169670	Bracket Clutch Cable
26	110452X	Washer, Lock	152	172758	Clutch Cable 38"/42"
27	106736X428	Deflector, Shield	153	169674	Washer Flat 3/8" Type B
28	19111016	Washer 11/32 x 5/8 x 16 Ga.	154	169675	Spring Retainer
29	106735X	Rod, Hinge	155	169671	Spring Retention Lvr Cltch Cab
30	157722	Screw Hex Thdrol	156	169672	Spacer Clutch Cable 3/8"
31	129963	Washer, Spacer	157	169669	Rod Clutch Cable 3/8"
32	153532	Pulley, Mandrel	158	17720410	Screw Hex Thd Cut 1/4-20 x 5/8
33	137266	Nut Lock 9/16		130794	Asm. Mandrel (includes key nos. 8-
36	131494	Pulley, Idler, Flat			10, 12-15, 31 and 33)
40	73680600	Nut, Crownlock 3/8 - 16 UNC		170317	Mower Deck, Complete
45	4497H	Retainer Spring 1: Zinc/Cad			
53	130840	Brake Assembly	NOT	- 411	( )[
54	133943	Washer, Hardened	NOT	E: All compo	onent dimensions given in U.S. inches
55	133840	Arm, Idler Assembly		1 inch = 2	5.4 mm
56	165723	Spacer, Retainer			

#### LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of one (1) year from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- 1. This warranty does not apply to the engine. Please contact your nearest dealer where they will send the machine to the engine manufacturer.
- 2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by your dealer.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In case of any problem within the boundaries of this warranty, contact the nearest department store, indicate the model number, serial number and the date of purchase of your machine. This warranty does not apply to accidental damages. All implicit warranties are limited to the same time frames. Or contact:

E.M. Services 54 Rue Lambrechts 92400 Courbevoie France Telephone: (1) 46678078 Fax: (1) 46678095

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES. ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN.



# SERVICE POLICY



TECUMSEH

TECUMSEH

Issued January 1980 Revised January 1991

# WARRANTY

# LIMITED WARRANTIES FOR NEW PEERLESS GEAR POWER TRAIN COMPONENTS

#### A. Products Warranted

Peerless Gear and Machine Division of Tecumseh Products Company ("Tecumseh"), subject to the limitations contained below, will, at its option, repair or replace, without charge for parts or labor only, any part of a new Power Train Component (which as used herein means and includes the transaxle, gear box, transmission, differential and right angle drives, and any part of the Power Train Component), EXCEPT any new Power Train Component incorporated in equipment used for commercial or rental purposes, which is found upon examination by any Tecumseh Authorized Service Outlet or by Tecumseh's factory in Grafton, Wisconsin, to be DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP if received by Tecumseh or a Tecumseh Authorized Service Outlet for such examination within TWO YEARS from the date of sale to the original consumer purchaser of Peerless Series 820, 900, 910, 915, 920, 930 transaxles and Series 1100 angle drive and ONE YEAR for all other Peerless products. New Power Train Components incorporated in equipment used for commercial purposes are warranted in the same manner and to the same extent EXCEPT such Power Train Components are warranted for NINETY (90) DAYS ONLY, and must be received by Tecumseh or by a Tecumseh Authorized Service Outlet for such examination within 90 days from the date of sale to the original purchaser. New Power Train Components Incorporated in equipment used for rental purposes are warranted in the same manner and to the same extent EXCEPT such Power Train Components are warranted for THIRTY (30) DAYS ONLY, and must be received by Tecumseh or a Tecumseh Authorized Service Outlet within 30 days from the date of sale to the original purchaser.

#### B. Products And Items Not Warranted

- 1. Alterations or Modifications of Power Train Components.
- 2. Accidents, Normal Maintenance, Failure to follow the Original Equipment Manufacturer's Manual.

This warranty covers only parts of new Power Train Components which are found upon examination to be defective in material or workmanship as delivered to the original purchaser. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, failure to follow the instructions contained in an Instruction Manual for the operation of the Power Train Component and parts. The cost of normal maintenance and replacement of service items which are not defective shall be paid for by the original purchaser.

#### C. Securing Warranty Service

Warranty service can be arranged for by contacting either a Tecumseh Authorized Service Outlet (any Tecumseh Registered Service Dealer, Tecumseh Authorized Service Distributor, or Tecumseh Central Warehouse Distributor) or by contacting Tecumseh, c/o Service Manager, Engine and Transmission Group Service Division, 900 North Street, Grafton, Wisconsin 53024. Warranty service can only be performed by a Tecumseh Authorized Service Outlet or by Tecumseh at its factory in Grafton, Wisconsin. At the time of requesting warranty service, evidence must be presented of the date of sale to the original purchaser. The purchaser shall pay any charges for making service calls and/or for transporting the product to and from the place where the inspection and/or warranty work is performed. The purchaser shall be responsible for any damage or loss incurred in connection with the transportation of Power Train Components and/or part(s) of the Power Train Components submitted for inspection and/or warranty work.

#### D. Limitation of Damages and Implied Warranties

The foregoing EXPRESSED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. Neither Tecumseh nor any of its affiliates makes any warranties, representations or promises, written or oral, as to the quality of the Power Train Component or any of its parts, other than as set forth herein.

ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, TO THE EXTENT THAT EITHER MAY APPLY TO ANY PART(S) OF POWER TRAIN COMPONENTS, SHALL BE LIMITED IN DURATION TO THE PERIODS OF THE EXPRESSED WARRANTIES DEFINED IN PARAGRAPH A HEREOF. IN NO EVENT WILL TECUMSEH BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES AND/OR EXPENSES. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state.

#### E. No Dealer Warranty

Tecumseh neither assumes nor authorizes any other person, natural or corporate, to assume for Tecumseh any other obligations or liabilities in connection with or with respect to any part(s) of a Power Train Component. The seller or dealer of part(s) of a Power Train Component has no authority, whatsoever, to make any representations or promises on behalf of Tecumseh or to modify the terms or limitations of Tecumseh's warranty in any way.